








Lock 'N Load Motorcycle Wheel Chocks

PARTS LIST: BK800

 A.	1 ea. - BK800 Cradle Assembly
 B.	2 ea. - 1/2" x 1 1/4" Carriage Bolt
 C.	2 ea. - 1/2" Flat Nylon Washer
 D.	2 ea. - 1/2" Nylon Lock Nut
 E.	1 ea. - BK100-2 Front Tire Strap

www.LOCKNLOADWHEELCHOCKS.com

Phone: 541-472-9297 - 3380 Fish Hatchery Rd. - Grants Pass, OR 97527



BK800 - Instruction Sheet

Upgrade Kit for BK103 Wheel Chock



- 1.) Insert 1/2" x 1 1/4" Carriage Bolt (B) into middle (of three square holes) hole "1" and square hole "2" located in the rear of the BK800 Cradle Assembly (A).
- 2.) Place 1/2" Nylon Washers (C) on to 1/2" x 1 1/4" Carriage Bolts (B) and insert from the inside of BK103 Wheel Chock Bracket. 1/2" Nylon Washers (C) must be placed between the BK800 Cradle Assembly (A) and the BK103 Wheel Chock Bracket, so the Cradle Assembly can adjust up and down, using the Nylon Washer(s) as spacer/pivot points.
- 3.) After completing steps 1 & 2, place BK800 Cradle Assembly (A) on to each Carriage Bolt (B) and hand tighten each 1/2" x 1" Nylon Lock Nut (D) on to the Carriage Bolts (B).
- 4.) When Cradle Assembly is properly attached in place, tighten each 1/2" x 1" Nylon Lock Nut (D) with a wrench. Be careful not to over-tighten, as the Cradle Assembly (A) must move easily (but not loosely) up and down when attached to the BK103 Wheel Chock.
- 5.) When Upgrade Kit is fully installed, use BK100-2 Front Tire Strap (E) to secure motorcycle when storing in the Wheel Chock.